


Standard Spring Loaded Live Centers

TYPE II		TYPE III		TYPE IV		TYPE V		TYPE VI	
Taper	Part No.	Taper	Part No.	Taper	Part No.	Taper	Part No.	Taper	Part No.
2 MT	17102	3 MT	17103	4 MT	17104	5 MT	17105	6 MT	17106
7 B&S	17407	9 B&S	17409	10 B&S	17410	12 B&S	17412	15 B&S	17415
8 B&S	17408	8 Jarno	17208	11 B&S	17411	13 B&S	17413	16 B&S	17416
6 Jarno	17206	9 Jarno	17209	10 Jarno	17210	14 B&S	17414	20 Jarno	17220
7 Jarno	17207	1 SS	17303	11 Jarno	17211	14 Jarno	17214	22 Jarno	17222
5/8 SS	17301	1 1/16 SS	17304	12 Jarno	17212	16 Jarno	17216	2 1/4 SS	17309
3/4 SS	17302	1 1/4 SS	17305	1 1/2 SS	17306	1 3/4 SS	17307	2 1/2 SS	17310
						2 SS	17308	3 SS	17311

Bell Head Spring Loaded Live Centers

TYPE II		TYPE III		TYPE IV		TYPE V		TYPE VI	
Taper	Part No.	Taper	Part No.	Taper	Part No.	Taper	Part No.	Taper	Part No.
2 MT	17122	3 MT	17123	4 MT	17124	5 MT	17125	6 MT	17126
7 B&S	17427	9 B&S	17429	10 B&S	17430	12 B&S	17432	15 B&S	17435
8 B&S	17428	8 Jarno	17228	11 B&S	17431	13 B&S	17433	16 B&S	17436
6 Jarno	17226	9 Jarno	17229	10 Jarno	17230	14 B&S	17434	20 Jarno	17240
7 Jarno	17227	1 SS	17323	11 Jarno	17231	14 Jarno	17234	22 Jarno	17242
5/8 SS	17321	1 1/16 SS	17324	12 Jarno	17232	16 Jarno	17236	2 1/4 SS	17329
3/4 SS	17322	1 1/4 SS	17325	1 1/2 SS	17326	1 3/4 SS	17327	2 1/2 SS	17330
						2 SS	17328	3 SS	17331

Interchangeable Bell Head Adapters



Center Type	STYLE 1			STYLE 2			STYLE 3			STYLE 4			STYLE 5		
	Part No.	A	B	Part No.	A	B	Part No.	A	B	Part No.	A	B	Part No.	A	B
II	00231	0.25	1.31	00232	1.24	1.82	00233	1.75	2.33	00234	2.26	2.84	00235	0.13	0.76
III	00331	0.35	1.83	00332	1.72	2.58	00333	2.46	3.32	00334	3.20	4.06	00335	0.19	1.12
IV	00431	0.36	2.27	00432	2.17	3.25	00433	3.14	4.22	00434	4.11	5.19	00435	0.23	1.37
V	00531	0.51	3.33	00532	3.21	4.80	00533	4.60	6.19	00534	6.06	7.65	00535	0.38	2.00
VI	00631	0.68	5.12	(Contact factory for availability).											